GENERAL INFORMATION




Fig. GI-10 Rear supportable point

TOWING

Tow forward at hook as shown in Figure GI-11. Do not tow at front suspension member or transverse link. Be careful not to apply impact load to the hook.

Admittable load of hook is less than 1,000 kg (2,205 lb).




Fig. GI-11 Front towing point

SERVICE JOURNAL OR BULLETIN REFERENCE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT